```
/**
 * Ofile opcontrol.c
 * Obrief Controls what happens in operator control
 * Copyright (C) 2017 Ethan Wells
 * This program is free software: you can redistribute it and/or modify it
 * under the terms of the GNU General Public License as published by the Free
 * Software Foundation, either version 3 of the License, or(at your option) any
 * later version.
 * This program is distributed in the hope that it will be useful, but WITHOUT
 * ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS
 * FOR A PARTICULAR PURPOSE. See the GNU General Public License for more
 * details.
 * You should have received a copy of the GNU General Public License along
 * with this program. If not, see <a href="https://www.gnu.org/licenses/">https://www.gnu.org/licenses/</a>
#include <string.h>
#include "../include/robot.h"
#define MOGO_HOLD 300
extern bool isAuto;
int digital (unsigned char joyNum,
            unsigned char channel,
            unsigned char b1,
            unsigned char b2) {
        return joystickGetDigital(joyNum, channel, b2) * -1 +
               joystickGetDigital(joyNum, channel, b1) * 1;
} /* digital */
void moveDrive();
void moveMogo();
void skillsMogo();
void moveArm();
void moveClaw();
void clawPID();
void autonLeft22();
void autonLeft22T();
void operatorControl() {
        printf("Starting Driver Control...\n");
```

```
reset();
update();
isAuto = false;
clawSettings.target = claw.sensor->value;
armSettings.target = arm.sensor->value;
/*
if (armLimit[0].value) {
        armSettings.target = ARM_QUARTER;
        PID(@armSettings);
*/
print("Beginning driver control loop\n");
bool isSkills = strstr(autons[selectedAuton].name, "skills");
while (true) {
        if (joystickGetDigital(1, 7, JOY_LEFT) &&
            joystickGetDigital(2, 7, JOY_LEFT)) {
                exit(0);
        }
        moveDrive();
        moveMogo();
        if (isSkills) {
                // skillsMogo();
                if (joystickGetDigital(2, 7, JOY_DOWN)) {
                        reset();
                        sensorReset(drive[0].sensor);
                        sensorReset(drive[1].sensor);
                        sensorReset(arm.sensor);
                        sensorReset(mogo.sensor);
                        sensorReset(&gyro);
                        autonLeft22();
                        /*
                        TaskHandle autoHandle = GO(autonLeft22T, NULL);
                        while (joystickGetDigital(2, 7, JOY_DOWN))
                                delay(20);
                        while (!joystickGetDigital(2, 7, JOY_DOWN))
                                delay(20);
                        if (taskGetState(autoHandle)) {
                                taskDelete(autoHandle);
                                mutexGive(gyro._mutex);
```

```
mutexGive(gyro.child->_mutex);
                                        mutexGive(arm.sensor->_mutex);
                                        mutexGive(mogo.sensor->child->_mutex);
                                        mutexGive(claw._mutex);
                                        mutexGive(arm._mutex);
                                        mutexGive(arm.child->_mutex);
                                        mutexGive(mogo.child->_mutex);
                                        for (int i = 0; i < 2; i++) {
                                                mutexGive(drive[i]._mutex);
                                                 mutexGive(drive[i].sensor->_mutex);
                                                mutexGive(armLimit[i]._mutex);
                                        7
                        }
                }
                moveArm();
                clawPID();
                update();
                delay(20);
        }
} /* operatorControl */
void moveDrive() {
        drive[0].power = deadBand(joystickGetAnalog(1, 3), 10) +
                         127 * digital(1, 7, JOY_UP, JOY_DOWN) +
                         127 * digital(1, 7, JOY_RIGHT, JOY_LEFT);
        drive[1].power = deadBand(joystickGetAnalog(1, 2), 10) +
                         127 * digital(1, 8, JOY_UP, JOY_DOWN) +
                         127 * digital(1, 8, JOY_LEFT, JOY_RIGHT);
} /* moveDrive */
void moveMogo() {
        int power = 127 * digital(1, 6, JOY_UP, JOY_DOWN) +
                     127 * digital(2, 5, JOY_UP, JOY_DOWN);
        if ((mogo.power == 127 || mogo.power == 9) && !power)
               power = 9;
        mogo.power = power;
} /* moveMogo */
void skillsMogo() {
        if ((mogo.sensor->value <= MOGO_HOLD) &&
```

```
!joystickGetDigital(1, 5, JOY_DOWN) &&
            !joystickGetDigital(2, 7, JOY_UP)) {
                mogo.power = clipNum(mogo.power,
                                     127,
                                     (MOGO_HOLD - mogo.sensor->value) * .9 + 13);
} /* skillsMogo */
void moveArm() {
        static unsigned long lastPress;
        if (digital(2, 6, JOY_DOWN, JOY_UP) || (millis() - lastPress < 90)) {
                arm.power = 127 * digital(2, 6, JOY_UP, JOY_DOWN);
                if (arm.power) {
                        lastPress = millis();
                if (armLimit[0].value) {
                        sensorReset(arm.sensor);
                        arm.power = clipNum(arm.power, 0, -127);
                } else if (armLimit[1].value) {
                        arm.sensor->zero = arm.sensor->value - 1000;
                                         = clipNum(arm.power, 127, 0);
                        arm.power
                armSettings.target = arm.sensor->value;
        } else if (armLimit[0].value) {
                  sensorReset(arm.sensor);
                armSettings.target = 0;
                arm.power
                                  = 0;
        } else if (armLimit[1].value) {
                arm.sensor->zero = arm.sensor->value - 1000;
                armSettings.target = 1000;
                arm.power
                                  = 0;
        } else {
                PID(&armSettings);
} /* moveArm */
void moveClaw() {
        if (deadBand(joystickGetAnalog(2, 4), 10)) {
                claw.power = joystickGetAnalog(2, 4);
        } else {
                claw.power = 0;
} /* moveClaw */
```

```
void clawPID() {
        static unsigned long lastPress;
        static int power;
       power = joystickGetAnalog(2, 4);
        if (power) {
                                   = power;
                claw.power
               clawSettings.target = claw.sensor->value;
               lastPress = millis();
        } else if (millis() - lastPress < 230) {</pre>
                clawSettings.target = claw.sensor->value + 25;
        } else {
               PID(&clawSettings);
} /* clawPID */
void autonLeft22T(void *none) {
        autonLeft22();
        taskDelete(NULL);
}
```