

```

/**
 * @file opcontrol.c
 * @brief Controls what happens in operator control
 * Copyright (C) 2017 Ethan Wells
 *
 * This program is free software: you can redistribute it and/or modify it
 * under the terms of the GNU General Public License as published by the Free
 * Software Foundation, either version 3 of the License, or (at your option) any
 * later version.
 *
 * This program is distributed in the hope that it will be useful, but WITHOUT
 * ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS
 * FOR A PARTICULAR PURPOSE. See the GNU General Public License for more
 * details.
 *
 * You should have received a copy of the GNU General Public License along
 * with this program. If not, see <https://www.gnu.org/licenses/>
 */

#include <string.h>
#include "../include/robot.h"

#define MOGO_HOLD 300

extern bool isAuto;

int digital(unsigned char joyNum,
            unsigned char channel,
            unsigned char b1,
            unsigned char b2) {
    return joystickGetDigital(joyNum, channel, b2) * -1 +
        joystickGetDigital(joyNum, channel, b1) * 1;
} /* digital */

void moveDrive();
void moveMogo();
void skillsMogo();
void moveArm();
void moveClaw();
void realClawPID();
void limitArmMogo();

void autonLeft22();
void autonLeft22T();

void operatorControl() {

```

```

#ifdef DEBUG_MODE
    printf("Starting Driver Control...\n");
#endif
reset();
update();
isAuto = false;

clawSettings.target = claw.sensor->value;
armSettings.target = arm.sensor->value;

/*
if (armLimit[0].value) {
    armSettings.target = ARM_QUARTER;
    PID(&armSettings);
}
*/

bool isSkills = strstr(autons[selectedAuton].name, "skills");

while (true) {
    if (joystickGetDigital(1, 7, JOY_LEFT) &&
        joystickGetDigital(2, 7, JOY_LEFT)) {
        exit(0);
    }

    moveDrive();
    moveMogo();

    if (isSkills) {
        // skillsMogo();
        if (joystickGetDigital(2, 7, JOY_DOWN)) {
            reset();
            sensorReset(drive[0].sensor);
            sensorReset(drive[1].sensor);
            sensorReset(arm.sensor);
            sensorReset(mogo.sensor);
            sensorReset(&gyro);
            autonLeft22();
        }
    }
    moveArm();
    moveClaw();
    limitArmMogo();
    update();

    delay(20);
}

```

```

    }
} /* operatorControl */

void moveDrive() {
    drive[0].power = deadBand(joystickGetAnalog(1, 3), 10) +
        127 * digital(1, 7, JOY_UP, JOY_DOWN) +
        127 * digital(1, 7, JOY_RIGHT, JOY_LEFT);
    drive[1].power = deadBand(joystickGetAnalog(1, 2), 10) +
        127 * digital(1, 8, JOY_UP, JOY_DOWN) +
        127 * digital(1, 8, JOY_LEFT, JOY_RIGHT);
} /* moveDrive */

void moveMogo() {
    int power = 127 * digital(1, 6, JOY_UP, JOY_DOWN) +
        127 * digital(2, 5, JOY_UP, JOY_DOWN);
    if ((mogo.power == 127 || mogo.power == 9) && !power)
        power = 9;
    mogo.power = power;
} /* moveMogo */

void skillsMogo() {
    if ((mogo.sensor->value <= MOGO_HOLD) &&
        !joystickGetDigital(1, 5, JOY_DOWN) &&
        !joystickGetDigital(2, 7, JOY_UP)) {
        mogo.power = clipNum(mogo.power,
            127,
            (MOGO_HOLD - mogo.sensor->value) * .9 + 13);
    }
} /* skillsMogo */

void moveArm() {
    static unsigned long lastPress, lastDPress;

    if (digital(2, 6, JOY_DOWN, JOY_UP) || (millis() - lastPress < 90)) {
        arm.power = 127 * digital(2, 6, JOY_UP, JOY_DOWN);

        if (arm.power) {
            lastDPress = false;
            lastPress = millis();
        }

        if (armLimit[0].value) {
            sensorReset(arm.sensor);
            arm.power = clipNum(arm.power, 0, -127);
        } else if (armLimit[1].value) {
            arm.sensor->zero = arm.sensor->value - ARM_CONE;
        }
    }
}

```

```

        arm.power          = clipNum(arm.power, 127, 0);
    }

    if (joystickGetDigital(2, 8, JOY_UP)) {
        lastDPress = true;
        armSettings.target = ARM_LOAD;
        PID(&armSettings);
    } else if (!lastDPress)
        armSettings.target = arm.sensor->value;
} else if (armLimit[0].value) {
    sensorReset(arm.sensor);
    armSettings.target = 0;
    arm.power          = 0;
} else if (armLimit[1].value) {
    arm.sensor->zero     = arm.sensor->value - ARM_CONE;
    armSettings.target = ARM_CONE;
    arm.power          = 0;
} else {
    PID(&armSettings);
}
} /* moveArm */

void limitArmMogo() {
    if (joystickGetDigital(2, 8, JOY_DOWN))
        return;

    if (mogo.sensor->value > MOGO_PART &&
        arm.sensor->value > ARM_HALF - 50 &&
        arm.sensor->value < ARM_3_5_QUARTER && arm.power < -25) {
        armSettings.target = ARM_HALF - 150;
        PID(&armSettings);
    } else if (mogo.sensor->value > MOGO_PART &&
        arm.sensor->value >= ARM_3_5_QUARTER && arm.power > 28) {
        armSettings.target = ARM_CONE;
        PID(&armSettings);
    }

    if (arm.sensor->value > ARM_3_QUARTER &&
        arm.sensor->value < ARM_CONE - 80 && mogo.power > 25)
        mogo.power = 0;
}

void moveClaw() {
    if (deadBand(joystickGetAnalog(2, 4), 10)) {
        claw.power = -joystickGetAnalog(2, 4);
    }
}

```

```

        clawSettings.target = claw.sensor->value + (50 * sgn(claw.sensor->velocity));
    } else {
        realClawPID();
    }
} /* moveClaw */

void clawPID() {
    static unsigned long lastPress;
    static bool lastDir;
    static int power;

    power = -joystickGetAnalog(2, 4);

    if (power) {
        lastDir          = power > 0;
        claw.power        = -power;
        clawSettings.target = claw.sensor->value;
        lastPress         = millis();
    } else if (millis() - lastPress < 275) {
        clawSettings.target = claw.sensor->value + 50;
    } else if (lastDir) {
        claw.power = 0;
    } else {
        PID(&clawSettings);
    }
} /* clawPID */

void realClawPID() {
    switch (digital(2, 8, JOY_LEFT, JOY_RIGHT)) {
        case 1:
            clawSettings.target = CLAW_CLOSED;
            break;
        case -1:
            clawSettings.target = CLAW_OPEN;
            break;
        default:
            break;
    }

    PID(&clawSettings);
}

void autonLeft22T(void *none) {
    autonLeft22();
    taskDelete(NULL);
}

```